




Wine Cooler

WR 28

OWNER'S MANUAL



WARRANTY INFORMATION

Your appliance is protected by this warranty under normal, personal, family or household use for One Year in the USA and Canada.

WARRANTY

Equator Advanced Appliances undertakes to the consumer-owner to repair or, at our option, to replace any part of this product which proves to be defective in workmanship or material under normal personal, family or household use, in the USA and Canada, for a period of one year from the date of original purchase. During this period, we will provide all labor and parts necessary to correct such defect, free of charge, if the appliance has been installed and operated in accordance with the Equator Advanced Appliances' written instructions with the appliance. Ready access to the appliance, for service, is the responsibility of the consumer-owner.

EXCLUSIONS

In no event shall the Equator Advanced Appliances be liable for incidental or consequential damages or for damages resulting from external causes such as abuse, misuse, incorrect voltage or acts God. This warranty does not cover service calls which do not involve defective workmanship or materials covered by this warranty. Accordingly, diagnosis and repair costs for a service call which does not involve defective workmanship or materials will be the responsibility of the consumer-owner.

Specifically, the following work is not covered under warranty and does not constitute warranty work:

- **Installation – e.g. improper hook-up of CO₂ cylinder or beer keg or leveling**
- **Maintenance – e.g. keeping the unit clean**
- **Damage – e.g. replacing broken parts**

Most work is covered. The defining factor is, has the machine malfunctioned (Equator Advanced Appliances is responsible) or has the customer omitted or done something to cause machine to malfunction (customer is responsible). Some States do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

WARRANTY SERVICE

This warranty is given by:

Equator Advanced Appliances
2801 W Sam Houston Parkway N, Ste. 125
Houston, TX 77043-1611
Tel: 713-464-3422
Fax: 713-464-2151
Toll Free: 800-935-1955

Website: www.EquatorAppliances.com

Service under this warranty must be obtained in the following way:
Call an Authorized Service Agent (obtain number of nearest agent from your dealer or by calling 1-800-776-3538). Under normal circumstances, Service will be provided during regular business hours (9:00 a.m. to 5:00 p.m. weekdays).

GENERAL

Since it is responsibility of the consumer-owner to establish the warranty period by verifying the original purchase date, the Equator Advanced Appliances recommends that a receipt, delivery slip or some other appropriate payment record be kept for that purpose. Remember to send in your Warranty Registration Card so that a proof of your purchase exists with the Equator Advanced Appliances.

You can also register online at **www.appliancedesk.com/warranty**. This warranty gives you specific legal rights, and you may also have other rights which vary from State to State.

Customer Comments are welcome by emailing us at **mail@EquatorAppliances.com**

SERVICE & SUPPORT

Service:	1-800-776-3538 custserv@appliancedesk.com
Parts & Accessories:	1-888-483-9627 parts@appliancedesk.com
Website:	www.appliancedesk.com

IMPORTANT SAFETY INSTRUCTIONS

⚡ WARNING ⚡	Follow these basic precautions to reduce the risk of fire, electrical shock, or injury when using your appliance,
<ul style="list-style-type: none">•• Read all instructions before using the appliance.• DANGER: Risk of child entrapment.• Discarded or abandoned appliances are still dangerous. . . even if they will “just sit in the garage a few days.”• Before you throw away your old appliance: Take off the doors. Leave the shelves in place so that children cannot easily climb inside.• Never allow children to operate, play with, or crawl inside the appliance.• Never clean appliance parts with flammable fluids. The fumes can create a fire hazard or explosion.• Do not store or use gasoline or any other flammable vapors and liquids in the vicinity of this or any other appliance. The fumes can create a fire hazard or explosion. <p style="text-align: center;">-Save these instructions-</p>	

- **INSTALLATION INSTRUCTIONS**

BEFORE USING YOUR APPLIANCE

- Remove the exterior and interior packing.
- Check to be sure you have all of the following parts:
 - 5 Shelves
 - 2 Keys
 - 1 Wine Rack
 - 1 Owner's Manual
- Before connecting the appliance to the power source, let it stand upright for approximately 2 hours. This will reduce the possibility of a malfunction in the cooling system from handling during transportation.
- Clean the interior surface with lukewarm water using a soft cloth.

INSTALLING YOUR APPLIANCE

- This appliance is designed to be free standing only, and should not be recessed or built-in.
- Place your appliance on a level floor that is strong enough to support the appliance when it is fully loaded. To level your appliance, adjust the front leveling leg at the bottom of the appliance.
- Allow 5 inches of space between the back and sides of the appliance, which allows the proper air circulation to cool the compressor.
- Position the appliance away from direct sunlight and sources of heat (stove, heater, radiator, etc.). Direct sunlight may affect the acrylic coating and heat sources may increase electrical consumption. Extreme cold ambient temperatures may also cause the appliance not to perform properly.
- Avoid placing the appliance in moist areas.
- Plug the appliance into an exclusive, properly installed-grounded wall outlet. Do not under any circumstances cut or remove the third (ground) prong from the power cord. Any questions concerning power and/or grounding should be directed toward a certified electrician or an authorized Equator Products service center.

ELECTRICAL CONNECTION

⚡ Warning ⚡

Improper use of the grounded plug can result in the risk of electrical shock. If the power cord is damaged, have it replaced by an authorized electrician or Equator service agent.

This appliance should be properly grounded for your safety. The power cord of this appliance is equipped with a three-prong plug which mates with standard three prong wall outlets to minimize the possibility of electrical shock.

Do not under any circumstances cut or remove the third ground prong from the power cord supplied. For personal safety, this appliance must be properly grounded.

The cord should be secured behind the appliance and not left exposed or dangling to prevent accidental injury.

The appliance should always be plugged into its own individual electrical outlet which has a voltage rating that matches the rating label on the appliance. This provides the best performance and also prevents overloading house wiring circuits that could cause a fire hazard from overheated. Never unplug the appliance by pulling the power cord. Always grip the plug firmly and pull straight out from the receptacle. Repair or replace immediately all power cords that have become frayed or otherwise damaged. Do not use a cord that shows cracks or abrasion damage along its length or at either end. When moving the appliance, be careful not to damage the power cord.

REVERSING THE DOOR SWING OF YOUR APPLIANCE

This appliance has the capability of the door opening from either the left or right side. The unit is delivered to you with the door opening from the left side. Should you desire to reverse the opening direction, please call customer service for reversal instructions.

OPERATING YOUR APPLIANCE

NOTE: The preset temperature at the factory is 50°F and it will show on the display when you press the UP and DOWN buttons for the first time.

SETTING THE TEMPERATURE CONTROL FOR EACH ZONE


You can press **SET** button to control the internal temperature for each zone.

The degrees indicator will appear in the display marked upper (top zone) and lower (bottom zone).

- Press the SET button once.
The LED indicator on the upper display will flash. Then press the UP or DOWN buttons to get the desired temperature.
- When you press the SET button again, the LED indicator on the lower display will flash. Then proceed to press the UP or DOWN buttons to get the desired temperature in the lower section.
- The temperature that you desire to set will increase 1°F or 1°C if you push the **UP** button once, on the contrary the temperature will decrease 1°F or 1°C if you push the **DOWN** button once.
- When you store mostly red wines, the temperature which you control by pushing the above two buttons need to be set between 59 to 65° F and the LED lamp near "RED" will be lit.
- When you store mostly white wines, the temperature needs to be set between 48 to 58° F and the LED lamp near "WHITE" will be lit.

- When you store mostly sparkling wines, the temperature needs to be set at between 41 to 47° F and the LED lamp near “SPARKL” will be lit.
- You can select temperature display setting from Fahrenheit to Celsius degree by pushing the °C button.
- You can select temperature display setting from Celsius to Fahrenheit degree by pushing the ° F button.
- Fahrenheit and Celsius degrees indicator will appear on either the upper or lower displays.

RED:	RED WINES	59 –65° F
WHITE:	WHITE WINES/DRY	48 - 58° F
SPARKL:	SPARKLING WINES/ROSE WINES	41 - 47° F



STORAGE

Many bottles may differ in size and dimensions. As such the actual number of bottles you may be able to store may vary.

NOTE: You can place 10 standard bottles in the upper zone and 18 standard bottles in the lower zone.

INTERIOR LIGHT

- Interior light is only available in the lower zone.
- You can turn the interior light on by pushing the LIGHT ON/OFF button.
- The light will turn off automatically if it remains ON for 10 minutes or more.

DOOR LOCK

The keys are located inside the plastic bag that contains the Owner’s Manual. Insert the key into the lock and turn it counterclockwise to unlock the door. To lock the door do the reverse operation making sure the metal pin is engaged completely. Remove the key and place it in a secure place for safe keeping.

CARE AND MAINTENANCE


REPLACING YOUR LIGHT BULB

NOTE:

All parts removed must be saved to do the replacement of the light bulb.

Before removing the light bulb, either unplug the appliance or disconnect the electricity leading into the appliance at the main power supply. Failure to do so could result in electrical shock or personal injury.

- Press the light switch to the “OFF” position.
- Remove the screw “5”.
- Remove the light bulb cover “4” by pulling the bottom end of the light bulb cover gently.
- Unscrew the bulb “2”.
- Replace with a 10-watt bulb that is the same shape and size.
- Replace the light bulb cover “4” and tighten screw “5”.



CLEANING YOUR APPLIANCE

- Unplug the appliance, and remove shelves.
- Wash the inside surfaces with a warm water and baking soda solution. The solution should be about 2 tablespoons of baking soda to a quart of water.
- Wash the shelves with a mild detergent solution.
- The outside of the appliance should be cleaned with mild detergent and warm water.
- Wring excess water out of the sponge or cloth before cleaning the area of the controls, or any electrical parts.
- Wash the outside cabinet with warm water and mild liquid detergent. Rinse well and wipe dry with a clean soft cloth.

CAUTION:

Failure to unplug the appliance could result in electrical shock or personal injury.

POWER FAILURE

Most power failures are corrected within a few hours and should not affect the temperature of your appliance if you minimize the number of times the door is opened.

NOTE: If the unit is unplugged, has lost power, or is turned off; you must wait 3 to 5 minutes before restarting/reconnecting the unit. If you attempt to restart before this time delay, the appliance will not start.

VACATION TIME

- **Short vacations:** Leave the appliance operating during vacations of less than three weeks.
- **Long vacations:** If the appliance will not be used for several months, remove all items and unplug the power cord. Clean and dry the interior thoroughly. To prevent odor and mold growth, leave the door open slightly, blocking it open if necessary.

MOVING YOUR APPLIANCE

- Securely tape down all loose items inside your appliance.
- Turn the leveling screw up to the base to avoid damage.
- Tape the doors shut.
- Be sure the appliance stays secure in the upright position during transportation. Also protect the outside of appliance with a blanket or similar item.

ENERGY SAVING TIPS

- The appliance should be located in the coolest area of the room, away from heat producing appliances, and out of the direct sunlight.

TROUBLESHOOTING GUIDE

You can solve many common appliance problems easily, saving you the cost of a possible service call. Try the suggestions below to see if you can solve the problem before calling the servicer.

PROBLEM	POSSIBLE CAUSE
Appliance does not operate. Appliance is not cold enough.	Not plugged in. The circuit breaker tripped or a blown fuse. Check the temperature control setting. Make sure the unit is away from direct sunlight and heat sources. The door is opened too often. The door is not closed completely. The door gasket does not seal properly.
Turns on and off frequently.	The room temperature is hotter than normal. The door is opened too often. The door is not closed completely. The temperature control is not set correctly. The door gasket does not seal properly.
The light does not work.	Not plugged in. The circuit breaker tripped or a blown fuse. The bulb has burned out. The switch is in the "OFF" position.
Vibrations. The appliance seems to make too much noise.	Check to assure that the appliance is level. The rattling noise may come from the flow of the refrigerant, which is normal. As each cycle ends, you may hear gurgling sounds caused by the flow of refrigerant in your appliance. Contraction and expansion of the inside walls may cause popping and crackling noises. The appliance is not level.
The door will not close properly.	The appliance is not level. The door was reversed and not properly installed. The gasket is dirty. The shelves are out of position.

CONTACT INFORMATION

SERVICE & SUPPORT:
custserv@ApplianceDesk.com
(800) 776-3538

Equator Advanced Appliances
2801 W Sam Houston Parkway N, Suite125
Houston, TX 77043-1611
Phone: 713-464-3422 Fax: 713-464-2151

All rights reserved.

Manual subject to change without notice